SONY®



Home Theatre System

Startup Guide

HT-RT3


Supplied accessories








Setting up the remote control




To mount the Bar Speaker and the Surround Speakers (SUR L/SUR R) on a Refer to the supplied Operating Instructions.




Connecting the speakers

Connect the speaker cords to match the color of the SPEAKERS jacks on the rear panel of the Subwoofer.





Connecting with a TV

Make sure that the HDMI cable is firmly inserted.




Turning on the system





- 1 Turn on the TV and then change the input of the TV to the input which the Subwoofer is connected.
- 2 Connect the AC power cord (mains lead) of the Subwoofer.
- 3 Press (b) (power)
- The front panel display lights up.

Listening to the sound



Press INPUT repeatedly until the device you want appears in the front panel display. Then, press 🖊 +/- repeatedly to adjust the volume of the system and press SW \(\square\) +/- repeatedly to adjust the volume of the Subwoofer.

Setup completed! Enjoy!


Please refer to the supplied Operating Instructions about the sound mode, and other functions.



Operating Instructions

Listening to music from a BLUETOOTH device

When pairing a BLUETOOTH device



1 Turn the BLUETOOTH function of the paired device to on.

To listen to music from the paired device

Press INPUT repeatedly to select "BT".



To pair the system with a BLUETOOTH device (Pairing)

- Place the BLUETOOTH device within 1 meter from the Subwoofer.
- 2 Press PAIRING on the Subwoofer.
- The blue LED indicator flashes quickly () during BLUETOOTH pairing. 3 Turn on the BLUETOOTH function, and then select "HT-RT3" after searching for it on the BLUETOOTH device.
- Perform this step within 5 minutes, otherwise pairing mode will be canceled. When the BLUETOOTH connection is established, the blue LED indicator lights up (). If passkey is required on the BLUETOOTH device, enter "0000".

When using One-touch connection (NFC)



4 Adjust the volume.

Blue LED indicator

- 1 Hold the remote device near to the N-Mark on the Subwoofer until the remote device vibrates.
- When the BLUETOOTH connection is established, the blue LED indicator lights up (). 2 Start playback of audio source on the remote device.
- Compatible remote devices
- Remote devices with a built-in NFC function (OS: Android™ 2.3.3 or later, excluding Android 3.x)



SongPal

A dedicated App for this model is available on both Google Play™ and App Store. Search for "SongPal" and download the free App to find out more about the convenient features.