



QUICK SETUP GUIDE

SAMSUNG

UNPACK



ONE CONNECT
ONE CONNECT CABLE



SAMSUNG SMART REMOTE
& BATTERIES (AA X 2)




POWER CORD



4EA
WALL MOUNT
ADAPTER




2EA
CABLE GUIDE




COVER TERMINAL

USER MANUAL
REGULATORY GUIDE
CLEANING CLOTH


ASSEMBLE




2 (R)




3 (L)




4




5






BN68-07834K-02




CONNECT



INITIAL SETUP



TV CONTROLLER



SMART REMOTE BUTTON GUIDE

